



JWBS-14SC

Band Saw

JR034

~230V 50Hz

PARTS LIST




Импортер в РФ: ООО «ИТА Технолоджи»
105082, Москва, Переведеновский пер., д. 17

Made in PRC / Сделано в КНР


P-JR034 2025-12

[illegible]


Parts Breakdown for JWBS-14SC Band Saw--B



Parts Breakdown for JWBS-14SC Band Saw—C



Parts Breakdown for JWBS-14SC Band Saw—D



Parts List for JWBS-14SC Band Saw

Index No.	Part No.	Description	Size	Qty
A1	GB6170	Hex.nut	M14X1.5-L	1
A2	GB276	Bearing	6202-2RZ	2
A3	JWBS14SC-A003	Upper wheel		1
A4	JWBS14SC-A004	PU tire		1
A5	JWBS14SC-A005	"C"ring	Φ35	2
A6	JWBS14SC-A006	Bolt		2
A7	JWBS14SC-A007	Pointer		1
A8	JWBS14SC-A008	Long bolt	M10X80	2
A9	GB96	Flat Washer	Φ10	4
A10	GB6170	Hex lock nut	M10	2
A11	GB5781	Hex Cap Screw	M6X12	4
A12	GB93	Spring washer	Φ6	4
A13	JWBS14SC-A013	Flange hex nut	M8	6
A14	JWBS14SC-A014	Upper shaft block		1
A15	JWBS14SC-A015	U-plate		1
A16	JWBS14SC-A016	Spring		1
A17	JWBS14SC-A017	Left support plate		1
A18	JWBS14SC-A018	Right support plate		1
A19	JWBS14SC-A019	Upper shaft		1
A20	GB70.1	Socket Head Cap Screw	M10X25	1
A21	JWBS14SC-A021	Threaded plate		1
A22	JWBS14SC-A022	Adjusting screw		1
A23	JWBS14SC-A023	Fixed bracket		1
A24	JWBS14SC-A024	Support block		1
A25	JWBS14SC-A025	Eccentric wheel assembly		1
A26	GB819	Pan Flat Head Screw	M5X14	8
A27	JWBS14SC-A027	Hinge	40	2
A28	GB41	Hex locking nut	M5	4
A29	GB818	Pan Head Cap Screw	M5X12	2
A30	JWBS14SC-A030	Looking window		1
A31	GB96	Flat Washer	Φ5	2
A32	GB41	Hex nut	M5	2
A33	GB41	Hex nut	M6	1
A34	GB93	Spring washer	Φ6	1
A35	GB96	Flat Washer	Φ6	2
A36	JWBS14SC-A036	Door stud		1
A37	JWBS14SC-A037	Upper door		1
A38	JWBS14SC-A038	Eye bolt	M10	1
A40	JWBS14SC-A040	hinge plate		2
A42	GB818	Pan Head Cap Screw	M5X12	2
A43	JWBS14SC-A043	Switch	DZ07C	1
A44	GB41	Hex nut	M4	2
A45	GB818	Pan Head Cap Screw	M6X8	4
A46	GB818	Pan Head Cap Screw	M4X10	2
A47	GB41	Hex nut	M5	2
A48	JWBS14SC-A048	Terminal block		1
A49	GB96	Flat Washer	Φ5	2
A50	GB96	Flat washer	Φ4	2
A51	JWBS14SC-A051	Carriage Bolt	M8X16	6
A52	JWBS14SC-A052	Adjusting knob		1
A53	JWBS14SC-A053	Lock knob		1
A54	GB93	Spring washer	Φ8	1
A55	JWBS14SC-A055	upper spacer bush		1
A56	GB5781	Hex Cap Screw	M8X25	4
A57	GB93	Spring washer	Φ8	4
A58	GB96	Flat Washer	Φ8	4
A59	JWBS14SC-A059	Locking handle		1
A60	JWBS14SC-A060	Press shaft		1

Parts List for JWBS-14SC Band Saw

Index No.	Part No.	Description	Size	Qty
A61	JWBS14SC-A061	Handle		1
A62	JWBS14SC-A062	Main panel		1
A63	GB80	Socket Set screw	M6X10	1
A64	JWBS14SC-A064	Tension hand wheel		1
A65	GB70.1	Socket Head Cap Screw	M6X25	1
A66	JWBS14SC-A066	Lock knob		1
A67	GB96	Flat washer	Φ6	1
A68	GB6170	Hex locking nut	M6	1
A69	GB818	Pan Head Cap Screw	M5X12	2
A70	JWBS14SC-A070	Looking window		1
A71	GB96	Flat Washer	Φ5	2
A72	GB41	Hex nut	M5	2
A73	JWBS14SC-A073	Blade guard assembly		1
B1	JWBS14SC-B001	Spring plate		1
B2	JWBS14SC-B002	Eccentric wheel		1
B3	GB6170	Hex locking nut	M8	1
B4	JWBS14SC-B004	Thin spring washer	Φ8	1
B5	JWBS14SC-B005	Spring pin	Φ4X20	1
B6	JWBS14SC-B006	Key fixing plate		1
B7	JWBS14SC-B007	Key of QKS8		1
B8	GB96	Flat Washer	Φ4	2
B9	GB818	Pan Head Cap Screw	M4X10	2
B10	GB41	Hex nut	M4	2
B11	JWBS14SC-B011	Door switch	QKS8	1
B12	GB818	Pan Head Cap Screw	M4X30	2
B13	JWBS14SC-B013	Guide bar bracket		1
B14	JWBS14SC-B014	Guide bar		1
B15	JWBS14SC-B15A	Upper guide Assembly		1
B15.1	JWBS14SC-B15.1	Knob		2
B15.2	JWBS14SC-B15.2	Special washer		2
B15.3	GB276	Bearing	61900-2RZ	4
B15.4	JWBS14SC-B15.4	Short shaft		2
B15.5	JWBS14SC-B15.5	Knurled lock knob		2
B15.6	JWBS14SC-B15.6	Knurled lock knob		1
B15.7	JWBS14SC-B15.7	Upper guide bracket		1
B15.8	JWBS14SC-B15.8	Link pin		1
B15.9	JWBS14SC-B15.9	"C"ring	Φ19	1
B15.10	JWBS14SC-B15.10	Bearing	619-8	1
B15.11	JWBS14SC-B15.11	Thrust bearing holder		1
B15.12	JWBS14SC-B15.12	Adjust shaft		1
B15.13	JWBS14SC-B15.13	"C"ring	Φ8	1
B15.14	GB80	Socket Set screw	M6X6	1
B15.15	JWBS14SC-B15.15	Spacing sleeve		1
B15.16	GB96	Flat Washer	Φ6	1
B15.17	GB70.1	Socket Head Cap Screw	M6X20	1
B16	GB96	Flat Washer	6mm	1
B17	GB93	Lock Washer	6mm	1
B18	GB70.1	Socket Head Cap Screw	M6x20	1
B19	GB819	Flat Head Cap Screw	M4x12	2
B20	JWBS14SC-B020	Windows		1
B21	GB41	Hex Nut	M4	2
B24	JWBS14SC-B024	"C"ring	Φ13	2
B25	GB70.1	Socket Head Cap Screw	M6X16	1
B26	JWBS14SC-B026	Support bracket		1
B27	GB70.1	Socket Head Cap Screw	M8X35	2
B28	GB93	Spring washer	Φ8	2
B29	GB96	Flat Washer	Φ8	2
B30	JWBS14SC-B030	Gear box		1
B31	JWBS14SC-B031	Worm shaft		1

Parts List for JWBS-14SC Band Saw

Index No.	Part No.	Description	Size	Qty
B32	JWBS14SC-B032	Gear		1
B33	JWBS14SC-B033	Protective plate		1
B34	JWBS14SC-B034	Special screw	M8X12	2
B35	GB70.2	Socket Head Cap Screw	M8X12	2
B36	GB93	Spring washer	Φ8	2
B37	JWBS14SC-B037	Long spring plate		1
B39	GB80	Socket Set screw	M8x8	1
B40	GB818	Pan Head Cap Screw	M6X10	1
B41	JWBS14SC-B041	Pointer		1
B42	JWBS14SC-B042	Protective plate		1
B43	JWBS14SC-B043	Soft magnet		1
B44	JWBS14SC-B044	Scale		1
B46	GB70.1	Socket Head Cap Screw	M6X10	2
B47	GB96	Flat Washer	Φ6	6
B48	GB70.1	Socket Head Cap Screw	M6X20	2
B49	GB818	Pan Head Cap Screw	M6X12	2
B50	GB41	Hex nut	M6	2
B51	GB80	Socket Set screw	M6X8	1
B52	JWBS14SC-B052	Spring pin	5X40	1
B54	JWBS14SC-B054	"E"ring	Φ8	2
B55	JWBS14SC-B055	Bush		1
B56	JWBS14SC-B056	Hand wheel		1
B57	GB80	Socket Set screw	M6X8	1
B58	JWBS14SC-B058	Shaft		1
B59	GB95.1	Small washer	Φ12	2
B60	JWBS14SC-B060	Short spring plate		1
B61	GB96	Flat washer	Φ6	2
B62	GB70.1	Socket Head Cap Screw	M6X8	2
B63	JWBS14SC-B063	Plug plate		1
B64	JWBS14SC-B064	socket		1
B65	GB96	Flat washer	Φ5	2
B66	GB818	Pan Head Cap Screw	M5X8	2
C1	JWBS14SC-C001	Lower door		1
C2	JWBS14SC-C002	Door stud		1
C3	GB96	Flat Washer	Φ6	1
C4	JWBS14SC-C004	Hinge	40	2
C5	GB819	Flat Head Cap Screw	M5X14	8
C6	JWBS14SC-C006	Lower Blade Guard		1
C7	JWBS14SC-C007	Knob		2
C8	GB5781	Hex Cap Screw	M5X35	2
C9	JWBS14SC-C009	Wood brush		1
C10	GB96	Flat Washer	Φ5	4
C11	GB41	Hex nut	M5	4
C12	JWBS14SC-C012	Insert block		1
C13	JWBS14SC-C013	Shelf		1
C14	GB5781	Hex Cap Screw	M5X10	2
C15	JWBS14SC-C015	PU tire		1
C16	JWBS14SC-C016	Lower wheel		1
C17	GB276	Bearing	6202	2
C18	JWBS14SC-C018	"C"ring	Φ35	2
C19	JWBS14SC-C019	Belt	6J609	1
C20	JWBS14SC-C020	Spindle pulley		1
C21	GB819	Flat Head Cap Screw	M8X35	3
C22	JWBS14SC-C022	Lower spindle		1
C23	JWBS14SC-C023	Motor pulley		1
C24	GB79	Socket Set screw	M8X8	2
C25	GB96	Large washer	Φ8	1
C26	GB93	Spring washer	Φ8	2
C27	GB5781	Hex Cap Screw	M8X20	2

Parts List for JWBS-14SC Band Saw

Index No.	Part No.	Description	Size	Qty
C28	JWBS14SC-C028	Key fixing plate		1
C29	JWBS14SC-C029	Key of QKS8		1
C30	GB96	Flat Washer	Φ4	2
C31	GB818	Pan Head Cap Screw	M4X10	2
C32	GB818	Pan Head Cap Screw	M4X30	2
C33	JWBS14SC-C033	Lock knob		1
C34	GB70.1	Socket Head Cap Screw	M6X25	1
C35	JWBS14SC-C035	Motor		1
C36	GB5781	Hex Cap Screw	M10X45	4
C37	GB93	Spring washer	Φ10	4
C38	JWBS14SC-C038	Adjust screw		4
C39	JWBS14SC-C039	Hex Nut	M20X1.5	1
C40	GB96	Flat Washer	Φ20	1
C41	JWBS14SC-C041	Spindle holder		1
C42	JWBS14SC-C042	Adjust plate		1
C43	JWBS14SC-C43A	Lower Guide Assembly		2
C43.1	JWBS14SC-C43.1	Knob		2
C43.2	JWBS14SC-C43.2	Special washer		2
C43.3	GB276	Bearing	61900-2RS	4
C43.4	JWBS14SC-C43.4	Short shaft		1
C43.5	JWBS14SC-C43.5	Knurled lock knob		2
C43.6	JWBS14SC-C43.6	Knurled lock knob		1
C43.7	JWBS14SC-C43.7	Lower guide bracket		1
C43.8	JWBS14SC-C43.8	Long shaft		1
C43.9	JWBS14SC-C43.9	"C"ring	Φ19	1
C43.10	GB276	Bearing	619-8-2RS	1
C43.11	JWBS14SC-C43.11	Thrust bearing holder		1
C43.12	JWBS14SC-C43.12	Adjust shaft		1
C43.13	JWBS14SC-C43.13	"C"ring	Φ8	1
C43.14	GB80	Socket Set screw	M6X6	1
C43.15	JWBS14SC-C43.15	Spacing sleeve		1
C43.16	GB70.1	Socket Head Cap Screw	M6X30	1
C43.17	GB70.1	Socket Head Cap Screw	M6X35	1
C52	JWBS14SC-C052	Hex nut	M14X1.5-L	1
C53	JWBS14SC-C053	Door switch	QKS8	1
C54	GB93	Spring washer	Φ6	1
C55	GB41	Hex nut	M6	1
C56	JWBS14SC-C056	Hinge plate		2
C57	JWBS14SC-C057	Hex locking nut	M5	4
C58	JWBS14SC-C058	Lower space bush		1
C59	GB41	Hex nut	M4	2
C60	GB96	Flat washer	Φ6	1
C61	GB6170	Hex locking nut	M6	1
C62	JWBS14SC-C062	Small plate		1
C63	JWBS14SC-C063	Cable bush	SK-16	3
C64	GB96	Flat washer	Φ4	2
C65	GB818	Pan Head Cap Screw	M4X8	2
C66	JWBS14SC-C066	Plug plate		1
C67	GB96	Flat washer	Φ5	2
C68	JWBS14SC-C068	Gland	M16	2
C69	GB818	Pan Head Cap Screw	M5X8	2
C70	JWBS14SC-C070	Plug		1
C81	GB818	Pan Head Cap Screw	M6X20	1
C82	JWBS14SC-C082	Round plate		1
C83	GB96	Flat washer	Φ6	1
C84	JWBS14SC-C084	Hex locking nut	M6	1
D1	JWBS14SC-D001	Aluminum fence		1
D2	GB70.1	Socket Head Cap Screw	M8X16	3
D3	GB93	Spring washer	Φ8	3

Parts List for JWBS-14SC Band Saw

Index No.	Part No.	Description	Size	Qty
D4	JWBS14SC-D004	Locking handle	M8	2
D5	JWBS14SC-D005	Fence head		1
D6	JWBS14SC-D006	Lock knob		1
D7	JWBS14SC-D007	Lock bar		1
D8	JWBS14SC-D008	Steel shaft		1
D9	JWBS14SC-D009	Dual head bolt		3
D10	GB41	Hex nut	M8	6
D11	GB96	Flat Washer	Φ8	9
D12	GB5781	Hex Cap Screw	M5X10	2
D13	GB96	Flat Washer	Φ5	2
D14	JWBS14SC-D014	Scale plate		1
D15	JWBS14SC-D015	Scale		1
D16	GB79	Socket Set screw	M4X4	4
D17	GB819	Flat Head Cap Screw	M4X10	1
D18	JWBS14SC-D018	Aluminum table insert		1
D19	GB41	Hex nut	M8	1
D20	JWBS14SC-D020	Table		1
D21	JWBS14SC-D021	Handle	M8X30	1
D22	GB41	Hex nut	M10	1
D23	GB5781	Hex Cap Screw	M10X50	3
D24	JWBS14SC-D024	Slide block		2
D25	JWBS14SC-D025	Trunnion		2
D26	GB96	Flat Washer	Φ6	6
D27	GB93	Spring washer	Φ6	6
D28	GB70.1	Socket Head Cap Screw	M6X16	6
D29	JWBS14SC-D029	Bracket		1
D30	GB96	Flat Washer	Φ10	2
D31	JWBS14SC-D031	Handle	M10X20	2
D32	GB818	Pan Head Cap Screw	M5X8	1
D33	JWBS14SC-D033	Pointer		1
D34	JWBS14SC-D034	Plastic screw		1
D35	GB80	Socket Set screw	M6X6	2
D36	GB5781	Hex Cap Screw	M8X30	2
D37	GB93	Spring washer	Φ8	6
D38	GB96	Large washer	Φ8	6
D39	GB80	Socket Set screw	M8X20	6
D40	JWBS14SC-D040	Fence body		1
D41	GB5781	Hex Cap Screw	M8X35	2
D42	GB41	Hex nut	M8	2
D43	GB5781	Hex Cap Screw	M8X20	2
D44	JWBS14SC-D044	Scale		1
D45A	JWBS14SC-D045A	Miter Gauge Assembly		1
D45	JWBS14SC-D045	Locking handle		1
D46	JWBS14SC-D046	Pull knob		1
D47	JWBS14SC-D047	pointer		1
D48	JWBS14SC-D048	Angle ruler		1
D49	JWBS14SC-D049	Flange bush		1
D50	JWBS14SC-D050	Thin washer		1
D51	JWBS14SC-D051	Sliding bar		1
D52	JWBS14SC-D052	special washer		1
D53	JWBS14SC-D053	Sliding pin		1
D54	JWBS14SC-D054	Spring		1
D55	JWBS14SC-D055	Angle scale		1
D56	JWBS14SC-D056	Spring screw	M6X12	3
D57	GB819	Flat Head Cap Screw	M6X8	1
D58	GB70.1	Socket Head Cap Screw	M5X12	2
D59	GB818	Pan Head Cap Screw	M6X20	1
D60	GB93	Spring washer	Φ6	1
D61	GB96	Flat washer	Φ6	1

Parts List for JWBS-14SC Band Saw

Index No.	Part No.	Description	Size	Qty
D62	GB6170	Hex locking nut	M6	1
D63	GB96	Flat washer	Φ10	1
	JWBS14SC-ID	ID Label (not shown)		1
	JWBS14SC-ML	Motor Label (not shown)		1
	JWBS14SC-JET	JET LOGO not shown		1
	JWBS14SC-L	ModelLabel (not shown)		1
	JWBS14SC-WR	Warning Label (not shown)		1

Wiring Diagram for JWBS-14SC Band Saw

	colour of strands	Litzenfarben	couleur des cordons
BK	black	schwarz	noir
WH	white	weiß	blanc
BU	blue	blau	bleu
YE	yellow	gelb	jaune
RD	red	rot	rouge
BN	brown	braun	brun
GY	grey	grau	gris
GNYE	green-yellow	grün-gelb	vert-jaune
OG	orange	orange	orange
VT	violet	violett	violet

	meaning of symbol	Bedeutung der Zeichen	interprétation
M	motor	Motor	moteur
S	switch	Schalter	interrupteur
C	condenser	Kondensator	condensateur
E	electronic unit	Elektronik Einheit	unité électronique
F	fuse	Sicherung	fusible
RS	reversing switch	Drehrichtungsschalter	commu. droite/gauche
CS	centrifugal switch	Fliehkraftschalter	déclencheur centrifuge
OL	overload cut-off	Überlastschuttschalter	déclencheur surcharge
L	machine lamp	Maschinenleuchte	lampe
LS	limit switch	Positionsendschalter	micro

JWBS-14SC Band Saw..... ~ 230V, 50Hz

